

Snackjet



120756

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

Phone: +49 5258 971-0
Fax: +49 5258 971-120
Service hotline: +49 5258 971-197
www.bartscher.com

Version: 1.0

Date of preparation: 2021-11-10

Original instruction manual

Technical Data

Name:	Cooking insert Snackjet
Article number:	120756
Material:	aluminium
Dimensions (W x D x H), in mm:	280 x 305 x 30
Weight, in kg:	0,71

We reserve the right to implement technical modifications.

Version / Design

- Designed for: Snackjet 200
- **Not** suitable for washing in dishwasher
- Suitable for use in microwave
- Important information: **Required for the preparation of all food**

Important indications

WARNING!

The cooking insert can be damaged by sharp acids by sharp acids and food containing salt.

When using the cooking insert, always make sure that acid and salt-containing products do not come into contact with the cooking insert or wipe them thoroughly before baking.

1. Clean the cooking insert under warm running water, with the use of a soft cloth or a sponge. Use mild cleaning agent if required.
2. Rinse the cooking insert with clean water.
3. Then dry thoroughly the cooking insert.