



300422

Technical specifications

Name	• Vacuum canister for vacuum packaging machine 100 (300741)
Code-No.:	• 300422
Material:	• plastic, transparent canister, white lid
Capacity:	• 1.5 litre
Dimensions:	• W 135 x D 135 x H 180 mm
Weight:	• 0.3 kg

- The vacuum canister is ideal for storing dry and brittle foodstuffs (e.g. cookies, cereals, etc.); powdered foodstuffs (e.g. flour, coffee, sugar); fresh and puree fruits and vegetables (e.g. strawberries, tomatoes, etc.), and prepared dishes (e.g. soup, sauce etc.).
- Foodstuffs retain freshness for up to five times longer.
- Vacuum canisters can be stacked one on top of the other.

Important tips:

- Before beginning use, check if the canister is damaged. **Never** use damaged canisters.
- **Do not** use a vacuum canister for marinating.
- **Do not** use a vacuum canister for packaging canned foodstuffs.



Operating temperature:
Only form a vacuum at
room temperature.



The canister is intended for
household vacuum packing
and storage.




Defrost without cover
in the microwave.

Cleaning

- Thoroughly clean the vacuum canister and lid after every use. The **lower portion** of the canister can be washed in the **upper basket** of a dishwasher, while the **lid** must be washed by hand in warm water with a mild cleaning agent. A dirty canister may lead to dangerous bacteria and fungus in foodstuffs.
- Do not use aggressive or harsh cleaning substances or solvents.
- Do not scrape off stubborn dirt with hard or sharp tools.

- Carefully clean the vacuum canister and lid.
- If the vacuum canister fails to maintain its vacuum, check the condition, cleanliness and position of seals according to **1a. and 1c. below**:

1. Remove the central button (**1a.**).
2. Remove the entire valve (**1**), seal (**2**) and lid (**3**).
3. Wash all parts by hand in warm water with a mild cleaning agent, then rinse with clean water.



4. Before replacing the lid elements check to ensure that all parts are completely dry. Replace the valve (**1**) inside the lid to ensure the seals are located properly (**1c.**). Assemble the other parts according to the illustration.


Vacuum packing in the vacuum canister



Place foodstuffs in the canister, leaving at least 3 cm of free space from the top edge.
Place the lid on the vacuum canister.



Connect the lid with the vacuum packing machine pump via the hose.



Press the button labelled „**Canister**“ on the control panel. The unit will create a vacuum inside the vacuum canister, and will shut off after the process is finished.



Disconnect the hose from the vacuum canister. To open, press the middle button on the canister and open the safety lock.

The sound of air flowing into the vacuum canister means that the contents have been properly vacuum packaged.

Bartscher GmbH
Franz-Kleine-Str. 28
33154 Salzkotten
Germany

phone: +49 5258 971-0
fax: +49 5258 971-120
Service-Hotline: +49 5258 971-197
www.bartscher.com