

Digital thermometer

A292.042



Technical information:


Measured temperature range: Precision:	-50 °C ~ + 150 °C (-58°F ~ + 302°F) +/- 1°C from -20°C ~ + 120°C +/- 2°F from -4°F ~ + 246°F
Automatic shut-down after:	5 minutes
Battery:	1 x 1,5V

Possible applications for meeting HACCP norms:

- Preparing food products
- Storing food products
- Cooling

Instructions:


- 1. Press "ON/OFF" to turn thermometer on
- Insert the sensor to a depth of approx.
 50 mm in the substance being checked.
- 3. Read the temperature after the measurement stabilizes.
- Press "HOLD" to save the measured value. Press "HOLD" again to delete the saved value.
- 5. Press "°C-°F" to change between Celsius and Fahrenheit.
- 6. Press "ON/OFF" to turn the thermometer off.



Changing the batters

1. Shift this button to the right.

2. Remove the battery holder and insert the new battery.





Bartscher GmbH Franz-Kleine-Str. 28 D-33154 Salzkotten Germany

phone: +49 (0) 5258 971-0 fax: +49 (0) 5258 971-120