# **B**artscher

Bedienungsanleitung Isolierkanne 2,5L mit Pumpsystem

D/A/CH

Instruction manual
Thermo jug 2,5L with pump system

GB/UK

Mode d'emploi Cafetière thermos 2,5L à pompe

F/B/CH

Manuale di utilizzo Thermos 2,5L a pompa

I/CH

Instrucciones de uso Jarra termo 2,5L con sistema dispensador

E

Manual de instruções Garrafa termica 2,5L com sistema de bombeamento

P

Gebruiksaanwijzing
Thermoskan 2,5L met pompsysteem

NL/B

Bedieningshandleiding
Termokande 2,5L med pumpesystem

DK

Инструкция по эксплуатации **Термос с помпой, 2,5 л.** 

RUS

Kullanma kılavuzu Pompalı termos 2,5L

TR

Instrukcja obsługi Termos 2,5L z pompką

PL

Návod k obsłużę Termoska 2,5L s pumpičkou

CZ

Upute za upotrebu Termos vrč s pumpicom, 2,5L

HR

Használati útmutató Pumpás termoszkanna 2,5L

Н

GR

Οδηγίες χρήσης Κανάτα θερμός 2,5L με σύστημα αντλίας



190125



## **Technical specifications**

| Name          | Thermo jug 2,5L with pump system   |
|---------------|--|
| Art. no.:     | 190125   |
| Construction: | With pump cover latch  |
| Material:     | Stainless steel reservoir;<br>Cover, pump and handle from artificial materials (black) |
| Capacity:     | 2.5 litres   |
| Dimensions:   | Ø 160 mm, H 330 mm   |
| Weight:       | 1.4 kg   |

#### Properties:

- Well-isolated two-layer casing;
- Perfect portions owing to smooth pump mechanism;
- Easy to use;
- Safe transport owing to fold-in handle and pump cover latch.

### Tips and advice



Wash thoroughly thermo jug and pump with hot water and a mild cleaning agent prior to each use.

- Filling the thermo jug is simple. Open the pump cover while pressing the buttons on the pump head, then raise the cover.
- Remove the pump tube and fill the thermo jug with the desired amount of hot or cold liquid. Replace the tube and close the cover until the buttons click into place.
- > To pour drinks from the thermo jug, open the latch on the pump cover by sliding it to the left (**OPEN**).
- Place a cup/glass or other container under the pump head and press down on the cover. The pump mechanism will begin to function. Press and hold until the container contains the desired amount of beverage.
- > Close the pump latch by sliding it to the right (**CLOSE**).







# (3) artscher

- In order for drinks in the thermo jug to remain at a constant temperature, it is advisable to preheat the thermo jug or in the case of cold drinks to cool the thermo jug. To ensure best results, depending on the type of beverage fill the thermo jug first with a small amount of hot or cold water and swirl around or leave in the thermo jug for a time prior to filling it with the desired beverage.
- > Do not fill the thermo jug with fizzy drinks or baby formula, as bacteria can grow.
- If coffee was in the thermo jug, wash it thoroughly prior to filling with another beverage in order to avoid any unwanted aftertastes.

#### Cleaning



- Remove the thermo jug cover only for cleaning. Open the cover using the buttons on the pump head.
- Press the connecting mechanism on the center of the cover connector and remove the cover



phone: +49 (0) 5258 971-0

fax:

+49 (0) 5258 971-120

- Clean the cover with warm water and a mild cleaning agent.
- Clean the thermo jug and pump tube after each use with warm water and a mild cleaning agent.
- Wipe the outside of the thermo jug with a soft, moist cloth.
- Hard water may leave calcium deposits in the thermo jug. Coffee generally dyes the interior and leaves a brown residue. To remove such deposits, use commercially available substances.
- Rinse the thermo jug thoroughly and **several times**, then leave open to dry.
- Never use harsh chemicals which may scratch the thermo jug.
- Replace the cover following cleaning.
- Never wash the thermo jug in the dishwasher.
- Never immerse the thermo jug in water.
- Never use scouring agents to clean the thermo jug.
- Use only a soft cloth and never use any type of harsh chemicals which may damage the stainless steel casing.

Bartscher GmbH Franz-Kleine-Str. 28 D-33154 Salzkotten Germany

- 4 -