



ST1800



825212

Original-Gebrauchsanleitung V3/0321





ENGLISH

Table of contents

1.Safety	
1.1 Safety instructions	
1.2 Key to symbols	
1.3 Proper use	
2. General information	
2.1 Liability and Warrantees	
2.2 Copyright protection	
2.3 Declaration of conformity	
3. Transport, packaging and storage	
3.1 Delivery check	
3.2 Packaging	
3.3 Storage	
4. Technical data	26
4.1 Overview of parts	
4.2 Technical specification	
5. Installation and operation	27
5.1 Installation	
5.2 Operation	
6. Cleaning	
7. Waste disposal	
······	•••

Bartscher GmbH Franz-Kleine-Str. 28 33154 Salzkotten Germany phone: +49 5258 971-0 fax: +49 5258 971-120 **Service-Hotline:** +49 5258 971-197 www.bartscher.com

Bartscher



Read this instruction manual before using and keep them available at all times!

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

Please keep these instructions and give them to future owners of the device.

1.Safety

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

All persons using the device must follow the recommendations and instructions in this instruction manual.

1.1 Safety instructions

- The device is not intended for use by individuals (including children) with physical or mental disabilities, insufficient experience, and/or insufficient knowledge unless such persons are under the care of a person responsible for their safety or have received instructions regarding appropriate use of the device.
- Children should be observed to ensure that they are not playing with the device.
- This device is not equipped with a thermostat regulating the room temperature. Do not use the device in small rooms if there are people there who are not able to leave the room on their own, unless during the operation of the device a permanent supervision is ensured.

- Never leave the device unattended when in use.
- Never use the device with a programmable switch, timer or an automatic switching device.
- This device may only be operated in technically proper and safe condition.
- Prevent access of children to the package materials like plastic bags and foamed polystyrene elements. **Suffocation hazard!**
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device.
 Do not attempt to repair the device yourself.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

DANGER! Electric shock hazard!

To avoid the hazard results please follow the safety instructions below.

- Never allow the power cable to come into contact with heat sources or sharp edges. The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled. Never place the device or other objects on the power cable.
- Do not lay the power cable over carpets or other inflammable materials. Do not cover the cable. Keep away the cable from operating range and do not immerse it into water.

Bartscher

- Check the power cord regularly for damage. Do not use the appliance if the power cord is damaged. If this cable is damaged, it must be replaced by customer service or a qualified electrician in order to avoid dangers.
- The supply cable must be disconnected from the socket only by pulling the plug.
- Never carry or lift the device by the supply cable.
- Never wrap the power cord around the infrared heater.
- In any case do not open the device housing. In case of electrical or mechanical modifications the **electric shock hazard** will occur.
- Do not place foreign objects in the device openings! This may result in electric shock and damage the equipment!
- The device may not be exposed to vibrations and other mechanical shocks.
- Although the infrared heater is splash-proof, do not use the device during rain.
- Never immerse the device, power cord or the plug in water or other fluids.
- Do not use any acid agents and make sure no water ingresses the device.
- Never operate the device with moist hands or standing on wet floor.
- Remove the plug from its socket:
 - when the device is not used,
 - in case of anomalies during operation,
 - before cleaning.

HOT SURFACE! Burn hazard!

Follow the safety instructions listed in order to avoid the hazard:

- During the operation, the housing and protective grid become very hot, do not touch these elements during the operation of the device.
- Also after switching the device off, it remains hot for some time afterwards; before cleaning the device, handling or moving it to a different place, leave the device to cool down.
- Never move the device during its operation.
- Keep children and animals away from the device. Children should never use the infrared heater.

WARNING! Fire or explosion hazard!

Follow the safety instructions listed in order to avoid the hazard:

- Do not use the device near the containers holding gas, petrol, paint, spirits, alcohol or inflammable objects. High temperature may lead to their evaporation and their coming into contact with the sources of ignition may result in deflagration, in effect leading to personal injuries and material damages.
- Infrared heater is designed for private use only. Never use the device in greenhouses, livestock buildings or similar buildings, because they often have inflammable objects or excessive dust which may also present a risk.
- Never dry clothes, towels or similar objects on the device. Risk of overheating and fire!
- In case of fire, before starting any fire-fighting actions, pull the plug from the socket. Ensure proper flow of fresh air.
 Note: Never extinguish fire with water while the plug is connected to the socket. Risk of electric shock!

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



This symbol highlights hazards which could lead to injury.



This symbol highlights dangerous situations which could lead to injury or death.



This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!



This symbol highlights dangerous situations which could lead to light injuries, or damage, malfunction, and/or destruction of the device.



This symbol highlights recommendations and information aimed for effective and trouble-free device operation.

1.3 Proper use

The operational safety of the device is assured only in case of proper use, according to the operation manual.

All technical activities like installation and maintenance must be performed by the qualified service personnel only.

Infrared heater is designed for inner and outer spaces, and may be used outdoors and in an enclosed space, provided that the safety instructions presented in this operating manual are observed.

The infrared heater is designed <u>only</u> for home use. Never use it in greenhouses, livestock buildings and similar buildings.



Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.

2. General information 2.1 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology.



Read this manual carefully and thoroughly before any operation of the device, and especially before turning it on!

Manufacturer is not liable for any damages or faults caused by:

- violation of advice concerning operation and cleaning;
- use other than designed;
- alterations made by user;
- use of inadequate spare parts.

We reserve the right to make technical changes for purposes of developing and improving the useful properties.

2.2 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.

The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

2.3 Declaration of conformity

The device complies with the current standards and directives of the EU. We certify this in the EC declaration of conformity. If required we will be glad to send you the according declaration of conformity.

F

3. Transport, packaging and storage 3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage


Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- do not store outdoors,
- keep it dry and dust-free,
- do not expose it to aggressive media,
- do not expose it to direct sunlight,
- avoid mechanical shocks and vibration,
- in case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly, if required refresh or renew.

4. Technical data

4.1 Overview of parts



4.2 Technical specification

Name	Electrical infrared heater ST1800
Code-No.:	825212
Material:	Aluminum, stainless steel base
Design:	 2 heating tubes of the infrared heater, with 900W each (Ruby Red tubes), 2-level switching, (3 settings) Main switch, ON/OFF switch Cable outlet at the rear of the heater, cable length: 1,8 m
Power:	1.8 kW / 220-240 V 50 Hz
Type of protection:	IP55
Dimensions:	W 495 x D 240 x H 1 610 mm
Weight:	16.1 kg
Accessories:	1 remote control

We reserve the right to make technical changes!

5. Installation and operation 5.1 Installation

• Unpack the device and remove the packaging material.



Never remove the rating plate and any warning signs from the device.

• Screw the infrared heater with the device base with the supplied screws M8*25.

Bartscher

Setting

- Put the device on an even, stable, dry surface which is resistant to high temperature.
- Never place the device on an inflammable surface.
- Do not place the device near inflammable materials (e.g. curtains) or objects (wardrobe etc.). Risk of fire!
- Keep a distance of at least 100 cm from the walls and other objects and 30 cm from the top of the device to the ceiling or other structures.
- **Never** place the device in the direct proximity of pools, ponds, bathtubs, in shower rooms.
- If possible, do not place the device in passages to avoid tilting as a result of accidental touching of the infrared heater.



The device is equipped with a safety device which automatically disconnects the heating tubes in case of hitting or tilting over of the infrared heater (e.g. in an instance of device tilting over due to high wind).

- When placing the device, make sure that the power cord is laid in such a way as to avoid tipping or entanglement.
- Place the device so that the plug is easily accessible so as to quickly disconnect the device from the power supply if the need arises.

Connection



The device can cause injuries due to improper installation! Before installation and connecting the local power grid specification should be compared with that of the device (see rating plate). Connect the device only in case of compliance!


Connect the device only to properly installed single socket with protective terminal.

- Never connect the device to the power source before the completion of installation.
- The electrical circuit of the socket must be secured to at least 16A. Connect the device only directly to the wall socket, use of extension cords or power strips is forbidden.

5.2 Operation

• Before the first use, clean the device according to the instructions presented in section 6 "Cleaning".

Control Panel



- **9** Receiver of infrared signal sent from the remote control (left heating tube)
- **10** LED heating indicator, left heating tube (red)
- 11 ON/OFF switch, left heating tube
- **12** Receiver of infrared signal sent from the remote control (right heating tube)
- **13** LED heating indicator, right heating tube (red)
- 14 ON/OFF switch, right heating tube
- 15 LED power indicator (red)

Remote control

• **The remote control** is supplied with the device. Using remote control buttons you can switch on or off the heating tubes of the infrared heater at any moment.

Left button of the remote control for switching on the left heating tube of the infrared heater



Right button

of the remote control — for switching on the right heating tube of the infrared heater

Switching the device on

- Connect the device to a single, grounded socket.
- Switch the device on using the main switch at the rear of the device. The LED power indicator will come on.
- The device is equipped with 2 heating elements of the infrared heater with 2-level switching

Level 1: half power - the left or right heating tube is activated selectively;

Level 2: full power - heating tube are activated

- Switch on the selected heating tube (left or right, or both) pressing appropriate ON/OFF buttons on the control panel or the remote control. Respective LED heating indicators will come on.
- · Heating tubes emitting infrared radiation will immediately start dissipating the heat.



Do not leave children unattended with the infrared heater. Children may control the device only under the adults supervision.

HOT SURFACE! Risk of burning!

During the operation, the infrared heater becomes very hot. Never touch the device during the operation and immediately after its shutdown.

• After the use, switch the infrared heater off with the main switch located at the rear of the device and disconnect it from the power (pull the plug from the socket!).

6. Cleaning



Disconnect the device from the power supply (unplug!) before cleaning. Let the device cool down.

The device is not designed to be rinsed with running water. Do not use a pressure washer to clean the device! Be careful and do not let the water into the device.



Never use aggressive or abrasive cleaning agents. Do not use flammable cleaning agents (e.g. gasoline or solvents)! Do not use sharp or pointed objects.

- Clean the device regularly.
- Wipe the housing and base of the device with a soft, moist cloth and then dry the cleaned surfaces thoroughly.
- o Clean the protective grid with a soft brush or vacuum cleaner.
- Use only soft cloth for cleaning of the device.

Storage of the device

- If the device is not used for a long time, clean the device according to the above mentioned description and store in a dry, clean place protected against frost and direct sunlight and inaccessible to children.
- o Cover the device to protect it against dust and dirt.
- o Do not place any heavy objects on the device.

7. Waste disposal

Old devices



The electric devices are marked with this symbol. You must not dispose of electric devices with household waste. When the device may not be longer used each consumer is obliged to dispose of the device at the dedicated local collection point, separately from household waste.

Electric devices should be used and disposed of properly to prevent the impact on the environment.

• Disconnect the device from the power supply and remove the power cord from the device.

Bartscher GmbH Franz-Kleine-Str. 28 33154 Salzkotten Germany phone: +49 5258 971-0 fax: +49 5258 971-120 **Service-Hotline:** +49 5258 971-197 www.bartscher.com