



700082G

ENGLISH
Translation
of the original instruction manual



Read these instructions before using and keep them available at all times!

1. General information	18
1.1 Information about the instruction manual	18
1.2 Key to symbols	18
1.3 Liability and Warrantees	19
1.4 Copyright protection	19
1.5 Declaration of conformity	19
2. Safety	20
2.1 General information	20
2.2 Safety instructions for use of the device	20
2.3 Intended use	21
3. Transport, packaging and storage	22
3.1 Delivery check	22
3.2 Packaging	22
3.3 Storage	22
4. Technical data	23
4.1 Overview of parts	23
4.2 Technical specification	24
5. Installation and operation	24
5.1 Safety instructions	24
5.2 Installation and connection	25
5.3 Operation	26
6. Cleaning and maintenance	28
6.1 Safety advice	28
6.2 Cleaning	29
6.3 Safety instructions for maintenance	29
7. Possible Malfunctions	30
8. Waste disposal	32

Bartscher GmbH
 Franz-Kleine-Str. 28
 D-33154 Salzkotten
 Germany

phone: +49 (0) 5258 971-0
 fax: +49 (0) 5258 971-120

1. General information

1.1 Information about the instruction manual

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

1.2 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



WARNING!

This symbol highlights hazards, which could lead to injury.

Please follow the instructions very carefully and proceed with particular attention in these cases.



WARNING! Electrical hazard!

This symbol draws attention to potential electrical hazards. If you do not follow the safety instructions, you may risk injury or death.



CAUTION!

This symbol highlights instructions, which should be followed to avoid any risk of damage, malfunctioning and/or breakdown of the device.



NOTE!

This symbol highlights tips and information, which have to be followed for an efficient and trouble-free operation of the device.

1.3 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology. If you have any questions, you should contact the manufacturer.



NOTE!

Read the instruction manual carefully before using the device. The manufacturer does not accept liability for any damage or malfunction resulting from not following the instructions for use.

The instruction manual should be kept near the device, easily accessible for anyone wishing to work with or using it. We reserve the right to make technical changes for purposes of developing and improving the useful properties.

1.4 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



NOTE!

The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

1.5 Declaration of conformity

The device complies with the current standards and directives of the EU.

We certify this in the EC declaration of conformity.

If required we will be glad to send you the according declaration of conformity.

2. Safety

This section provides an overview of all important safety aspects.

In addition every chapter provides precise safety advice for the prevention of dangers which are highlighted by the use of the above mentioned symbols.

Furthermore, attention should be paid to all pictograms, markers and labels on the device, which must be kept in a permanent state of legibility.

By following all the important safety advice you gain an optimal protection against all hazards as well as the assurance of a safe and trouble-free operation.

2.1 General information

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

Knowing the contents of the instruction manual as well as avoiding mistakes and thus operating this device safely and in a fault-free manner is very essential to protect yourselves from the hazards.

To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.

This device may only be operated in technically proper and safe condition.

2.2 Safety instructions for use of the device

The specifications regarding the industrial safety are based on the Regulations of the European Union applicable at the time of manufacturing the device.

If the device is used commercially, the user is obliged to ensure that the said industrial safety measures concur with the state of the rules and regulations applicable at the time in question for the entire period of use of the device and to comply with the new specifications.

Outside the European Union, the industrial safety laws applicable at the place of installation of the device and the regional territorial provisions must be complied with.

Besides the industrial safety instructions in the instruction manual, the general safety and accident prevention regulations as well as environment protection regulations applicable for area of application of the device must be followed and complied with.



CAUTION!

- The device can be used by children **8 years and up**, as well as by people with disabilities and those with limited experience/knowledge as long as they are under supervision or have been instructed on proper use of the device and its possible dangers.

- **Children** should not play with the device.
- Cleaning and **maintenance cannot be performed by children** younger than 8 years old and must be done under supervision.
- **Children under the age of 8 years old** must be kept away from the device and its power cord.
- Please keep these instructions and give them to future owners of the device.
- All people using the device should follow the instructions and tips contained in these instructions.
- Only use the device indoors.

2.3 Intended use

Safe operation is only guaranteed when using the device for its intended purpose.

Any technical interventions, as well as assembly and maintenance are to be made by a qualified customer service only.

The device is intended for home use or in similar places such as:

- in kitchens for store or office employees or in other service locations;
- in suburban properties;
- by guests of hotels, motels and other places of accommodation;
- in Bed & Breakfasts.

The bottle cooler is intended only for **cooling beverages** contained in bottles.

Do not use the bottle cooler for:

- the storage of flammable or explosive items such as petrol, ether, kerosene, alcohol or glues;
- the storage of pharmaceutical products or preserved blood.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.

3. Transport, packaging and storage

3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



NOTE!

If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage


Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- Do not store outdoors.
- Keep it dry and dust-free.
- Do not expose it to aggressive media.
- Do not expose it to direct sunlight.
- Avoid mechanical shocks and vibration.
- In case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly.
If required refresh or renew.

4. Technical data

4.1 Overview of parts



- ① Double-pane glass door
- ② Shelf for bottles
- ③ Flat shelf
- ④ Legs, 2 front legs height-adjustable
- ⑤ Grate
- ⑥ Housing
- ⑦ Door handle

4.2 Technical specification

Name	Bottle cooler
Code-No.:	700082G
Capacity:	28 bottles / 88 litres
Door construction:	Double-pane glass, mounted on right side, adjustable mounting
Temperature regulation:	Fluid (1-7)
Temperature range:	2 °C – 10 °C
Coolant / quantity:	R600a /25 g
Power:	0.085 kW / 220-240 V~ 50 Hz (LED lighting 0.8 W)
Climate class:	N
Dimensions:	W 430 x D 480 x H 825 mm
Weight:	24.5 kg
Equipment:	6 shelves (5 shelves for bottles + one flat shelf)

We reserve the right to make technical changes!

5. Installation and operation

5.1 Safety instructions



WARNING! Risk of electric shock!

The device must only be connected to a properly installed single socket with protective contact.

Never remove the power cable by pulling the cable itself; always grab the plug housing.

- Never allow the power cable to come into contact with heat sources or sharp edges. The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled.
- Never place the device or other objects on the power cable.
- Do not lay the cable over carpets or heat insulations. Do not cover the cable. Keep away the cable from operating range and do not dunk it into water.

- Do not use the device in case it does not function properly, has been damaged or dropped.
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- Do not move or tilt the device when in operation.



WARNING! Hazard via electrical current!

Avoid contact between the device and water. Do not allow the water to be affected by rain, dripping water or other forms of moisture. This may lead to damage to the device or electric shock.



WARNING! Hazard via electrical current!

The device can cause injuries due to improper installation!

Before installation the local power grid specification should be compared with that of the device (see type label).

Connect the device only in case of compliance!

Take note of the security advice!

5.2 Installation and connection


- Discard the complete packing material after unpacking the device.
- Place the device on top of an even and safe surface which supports the weight of the device.
- Not **at any time** should you place the device on an inflammable surface (such as: table cloth, carpet, etc.).
- **Do not** place the device in the vicinity of open sources of fire, electric cookers, furnaces or other sources of heat such as e.g., in places exposed to direct sunlight. The heat can damage the surface of the device, as well as have a negative effect on the cooling power and increase the consumption of energy.
- To avoid damage to the compressor, do not tilt the device to an angle greater than 45° during setup or transport. Be careful when touching the condenser and doors, as damage to them will negatively impact the working of the device.
- 2 front height-adjustable legs set so as to ensure stability.
- Place the device in such a manner that there is a minimum of 10 cm between it and other objects, including walls, in order to ensure proper air circulation.

- Do not place the device where humidity or temperature are high as the device may be damaged.
- Do not drill holes in the device nor mount other objects to it.
- Do not store any heavy, poisonous or rusting objects.
- The electrical circuit in the socket must be secured to at least 16A. Only connect the device directly to the wall socket; do not use any extension cords or power strips.
- Place the device so that the plug is easily accessible and can be quickly removed from its socket in case of necessity.

5.3 Operation

- Before using the device and its equipment, wash with warm water and a mild cleaning agent. Rinse with clean water, then dry thoroughly.
- Before connecting the device to a power source leave the device upright for 4 hours.
- Connect the device to a single grounded outlet.

Controls



Lighting

- The device is equipped with an internal LED light and switch located inside the device.
- The internal light can be turned on (position **ON**) and off (position **OFF**) as needed using the switch.


Temperature regulation

- The temperature is set using the temperature dial, located inside the device at its top.
- In order to set the temperature, turn the temperature dial clockwise to the desired position (between 1 -7).
- Position "1" is the highest setting, and "7" the lowest temperature (temperature values, see 4.2 "**Technical information**").
- To turn the device off, turn the temperature regulator to the position marked "0".
- When the device is turned on for the first time or has remained unused for a longer period, set the temperature dial to "7" for at least 3-4 hours prior to placing bottles inside the cooler. Next, set the desired temperature.


Shelves / grates

- The bottle cooler is equipped with 5 shelves for bottles and 1 flat shelf. Shelves for bottles and the flat shelf are removable.

- The shelves for bottles ② are mounted in the slot located at the rear of the interior, to avoid slipping when removing bottles. To remove shelves for bottles, lift them slightly.
- The arch at the rear of the shelf for bottles prevents bottles from touching the rear wall, allowing for the free circulation of air throughout the device.



- The flat shelf ③ is intended for beverages in other types of containers.
- The grate ⑤ at the bottom of the device prevents bottles at the bottom from rolling out when the door is opened.



Tips and advice

- The bottle cooler is best for storing 0.75 litre bottles. The maximum capacity is based on bottles of this size.
- When filling the device, always ensure that the bottles do not block the door from closing.
- Placing a large number of bottles at once inside the device lengthens the time needed for them to cool to the desired temperature.
- To ensure optimal temperature selection, store bottles containing the same type of beverage if possible.
- A greater number of full bottles in the cabinet, as well as keeping the door open for a long time, increase energy use. Do not overfill the device, and do not leave the door open longer than necessary.
- To minimize temperature loss in the device, the door should be kept open for the shortest possible time. Do not open the door more frequently than necessary.
- In the event of a power outage, avoid opening the door to prevent loss of cold air.
- After a power outage or after removing the device's plug from its socket, do not connect the device to a power source for at least 5 minutes.

6. Cleaning and maintenance

6.1 Safety advice

- Before beginning with repair or cleaning works make sure the device has been disconnected from power supply and has cooled down.
- Do not use any acid agents and make sure no water ingresses the device.
- To protect yourself from electric shock, **never** immerse the device, its cables and the plug in water or other liquids.



CAUTION!

The device is not suited for direct washing via water jets.

Therefore, you must not use any kind of pressure water jet for cleaning the device!

6.2 Cleaning

- Clean the device regularly.
- Remove the shelves for bottles and the flat shelf from the device. Wash them with a mild cleaning agent and soft cloth, then dry thoroughly.
- Wash the bottle cooler on the inside and outside with warm water, a soft cloth and a mild cleaning agent.
- Rinse with clean water.
- Regularly clean the door and door seals with a moist cloth.



ATTENTION!

Never use hot water to clean the device!

Never use aggressive cleaning substances such as scouring powder, alcohol-based substances, solvents, petrol, etc. that may negatively affect the device's plastic elements and/or paint.

- After cleaning, dry and polish the surface thoroughly with a dry cloth

If the bottle cooler will be unused for a longer period of time:

- Turn the device off (temperature dial to "0") and remove the plug from its socket.
- Remove all beverages from the bottle cooler.
- Wash the interior and exterior of the device.
- Leave the door open for the bottle cooler to dry thoroughly, which will help avoid unpleasant odors and mold.

6.3 Safety instructions for maintenance

- Inspect the power cable regularly for damage. Never use the device if the cable is damaged. If the power cable is damaged, have an authorised service center or qualified electrician replace it.
- In case of damage or malfunction, please contact your stockist or our customer service centre. Pay attention to the troubleshooting tips in pt. 7.
- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**

7. Possible Malfunctions

Problem	Cause	Solution
No cooling	<ul style="list-style-type: none"> • The plug is not connected to the socket • Damaged fuse • Loss of electrical power • Faulty thermostat 	<ul style="list-style-type: none"> • Connect the plug to the socket • Check the power supply. Check the device by plugging it into another socket • Check the power supply • Contact a salesperson
Too high of a temperature in the device	<ul style="list-style-type: none"> • Direct sunlight or located near a heat source • Improper air circulation in the device. • The door is improperly closed or was left open too long • The door seal is damaged • The spacing between the stored bottles is too small or there are too many bottles in the device • Too low of a temperature 	<ul style="list-style-type: none"> • Move the device away from the heat source • Ensure a sufficient distance from walls and other objects • Close the door properly and minimize the time of opening the door • Contact a salesperson • Ensure the correct distance between the bottles, remove excess • Adjust the thermostat lower
Too low of a temperature in the device	<ul style="list-style-type: none"> • Too high of a temperature 	<ul style="list-style-type: none"> • Adjust the thermostat higher
Noise level too high	<ul style="list-style-type: none"> • The device is not standing on a level surface • The device touches walls or other objects 	<ul style="list-style-type: none"> • Set the device on a level surface • Ensure a sufficient distance from walls or other objects

Problem	Cause	Solution
Water condensates inside the device	<ul style="list-style-type: none"> Slightly opened door The door is open too long 	<ul style="list-style-type: none"> Check that nothing prevents the closure of the door. Close the door Minimize the time the door is open. Limit opening the door
Water condensates outside the device	<ul style="list-style-type: none"> Slightly open door, too great of a difference between the cold air from the device and the room temperature 	<ul style="list-style-type: none"> Check that nothing prevents the closure of the door. Close the door
The door does not close properly	<ul style="list-style-type: none"> The device is not standing on a level surface The door seal is dirty or deformed 	<ul style="list-style-type: none"> Set the device on a level surface Clean the seal, replace in the event of deformation. Contact a salesperson

The above described problem cases are given for orientation and as examples. Should these or similar problems occur, please turn off the machine immediately and don't use it anymore. In order to check and repair your machine, please contact a qualified expert or the manufacturer immediately.

The following are not malfunctions:

1. Sound of flowing eater. This sound occurs during normal use of the device. This is the cooling device inside the refrigerator.
2. Condensation forming on external glass surfaces in times of high humidity is normal. Wipe condensation with a dry cloth.
3. The compressor's surface may be hot during normal use.



WARNING! Danger of burns!

Do not touch the compressor's surface with bare hands.

8. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.



NOTE!



For the disposal of the device please consider and act according to the national and local rules and regulations.

Bartscher GmbH
Franz-Kleine-Str. 28
D-33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120