

2WL550 1/1 GN



114266

ENGLISH

Table of contents

1. Safety	18
1.1 Key to symbols	18
1.2 Safety instructions	19
1.3 Proper use	23
2. General information	24
2.1 Liability and Warrantees	24
2.2 Copyright protection	24
2.3 Declaration of conformity	24
3. Transport, packaging and storage.....	25
3.1 Delivery check	25
3.2 Packaging.....	25
3.3 Storage.....	25
4. Technical data	26
4.1 Overview of parts	26
4.2 Technical specification	27
5. Installation and operation.....	28
5.1 Instalation	28
5.2 Operation.....	30
6. Cleaning	31
7. Waste disposal	32

Bartscher GmbH
Franz-Kleine-Str. 28
33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120



Read this instruction manual before using and keep them available at all times!

This instruction manual contains information about the installation, operation and maintenance of the device and should be consulted as an important source of information and reference guide.

Awareness of the safety instructions and instructions for use in this manual will ensure the safe and correct use of the device.

In addition to the information given here, you should comply with any local Health and safety Controls and generally applicable safety regulations.

The instruction manual forms part of the product and should be kept near the device and easily accessible for anyone carrying out the installation, servicing, maintenance or cleaning.

Please keep these instructions and give them to future owners of the device.

1. Safety

This device is designed in accordance with the presently applicable technological standards. However, the device can pose a danger if handled improperly and inappropriately.

All persons using the device must follow the recommendations and instructions in this instruction manual.

1.1 Key to symbols

In this manual, symbols are used to highlight important safety instructions and any advice relating to the device. The instructions should be followed very carefully to avoid any risk of accident, personal injury or material damage.



DANGER!

This symbol highlights hazards which could lead to injury.



WARNING!

This symbol highlights dangerous situations which could lead to injury or death.



HOT SURFACE!

This symbol is a warning that the device surface is hot when in use. Ignoring this warning may result in burns!



CAUTION!

This symbol highlights dangerous situations which could lead to light injuries, or damage, malfunction, and/or destruction of the device.



NOTE!

This symbol highlights recommendations and information aimed for effective and trouble-free device operation.

1.2 Safety instructions

- The device is not intended for use by individuals (including children) with physical or mental disabilities, insufficient experience, and/or insufficient knowledge unless such persons are under the care of a person responsible for their safety or have received instructions regarding appropriate use of the device.
- Children should be observed to ensure that they are not playing with the device.
- **Never** leave the device unattended when in use.
- Only use the device indoors.
- This device may only be operated in technically proper and safe condition.
- Prevent access of children to the package materials like plastic bags and foamed polystyrene elements. **Suffocation hazard!**

- Only a qualified technician and using original spare parts and accessories should carry out repairs and maintenance of the device. **Do not attempt to repair the device yourself.**
- Do not use any accessory or spare parts that have not been recommended by the manufacturer. These can be dangerous for the user or lead to damages of the device or personal injury, and further, the warranty expires.
- To prevent hazards and to ensure optimum efficiency, no modifications or alterations to the device that are not explicitly approved by the manufacturer may be undertaken.



DANGER! Electric shock hazard!

To avoid the hazard results please follow the safety instructions below.

- Never allow the power cable to come into contact with heat sources or sharp edges. The power cable should not hang over the side of the working surface. Ensure that no one can step on or trip over the cable.
- The power cable must not be folded, bent or tangled, and must always remain fully unrolled. Never place the device or other objects on the power cable.
- Do not lay the power cable over carpets or other inflammable materials. Do not cover the cable. Keep away the cable from operating range.
- Check the power cord regularly for damage. Do not use the appliance if the power cord is damaged. If this cable is damaged, it must be replaced by customer service or a qualified electrician in order to avoid dangers.

- The supply cable must be disconnected from the socket only by pulling the plug.
- Never carry or lift the device by the supply cable.
- In any case do not open the device housing. In case of electrical or mechanical modifications the **electric shock hazard** will occur.
- Do not use any acid agents and make sure no water ingresses the device.
- **Never** operate the device with moist hands or standing on wet floor.
- Remove the plug from its socket:
 - when the device is not used,
 - in case of anomalies during operation,
 - before cleaning.



HOT SURFACE! Burn hazard!

To avoid the hazard results please follow the safety instructions below.

- During the operation the ventilated aluminium reflectors and the infrared lamp become hot. Do not touch them with bare hands. Use appropriate protective gloves!
- The reflectors and the heating lamp remain hot also for some time after turning off, so before cleaning or moving the device wait until it cools down.
- The GN container with food remains hot during heat maintaining. While removing food from GN container use protective gloves or kitchen towels!



WARNING! Fire or explosion hazard!

To avoid the hazard results please follow the instructions below.

- To avoid the fire hazard and the damages of the device **never** place the kitchen utensils, towels, paper, etc. on the heating plate.
- Never use the device near flammable materials (such as alcohol, spirits, petrol etc). High temperature may cause their evaporation and due to contact with the ignition sources the deflagration may occur, and in result the injuries and damages.
- In case of fire before the fire extinguishing activities remove the plug from the socket.

Caution: Do not spill water on the device which is still energised.
Electric shock hazard!

1.3 Proper use

The operational safety of the device is assured only in case of proper use, according to the operation manual.

All technical activities like installation and maintenance must be performed by the qualified service personnel only.

The infrared heating bridge is designed only for **keeping food warm**.

Do not use the infrared food warmer for:

- heating rooms;
- heating liquids or materials etc. which are flammable, dangerous or volatile.



CAUTION!

Any use going beyond the intended purpose and/or any different use of the device is forbidden and is not considered as conventional.

Any claims against the manufacturer or his authorized representative as a consequence of experiencing damages resulting from unconventional use are impossible.

The operator is liable for all damages resulting from inappropriate use.

2. General information

2.1 Liability and Warrantees

All the information and instructions in this manual take into account standard safety regulations, current levels of technical engineering as well as the expertise and experience we have developed over the years.

The instruction manual was translated with all due care and attention. However, we do not accept liability for any translation errors. The German version of this instruction manual is definitive.

If the delivery consists of a special model, the actual scope of delivery may differ from the descriptions and illustrations in this manual. This is also the case for special orders or when the device has been modified in line with new technology.



CAUTION!

Read this manual carefully and thoroughly before any operation of the device, and especially before turning it on!

Manufacturer **is not liable** for any damages or faults caused by:

- violation of advice concerning operation and cleaning;
- use other than designed;
- alterations made by user;
- use of inadequate spare parts.

We reserve the right to make technical changes for purposes of developing and improving the useful properties.

2.2 Copyright protection

The instruction manual including any texts, drawings, images or other illustrations is copyright. No part of this publication may be reproduced, transmitted or used in any form or by any means without permission in writing from the manufacturer. Any person who commits any unauthorized act in relation to this publication shall be liable to claims for damages. All rights reserved.



NOTE!

The contents, texts, drawings, pictures and any other illustrations are copyright and subject to other protection rights. Any person unlawfully using this publication is liable to criminal prosecution.

2.3 Declaration of conformity



The device complies with the current standards and directives of the EU. We certify this in the EC declaration of conformity. If required we will be glad to send you the according declaration of conformity.

3. Transport, packaging and storage

3.1 Delivery check

Please check the delivery upon completeness and transport damage immediately after receipt. In case of visible damage do not accept or accept the delivery with reservation only.

Note the extent of damage on the carrier's bill of delivery. Trigger off the complaint.

Hidden damages should be reclaimed immediately after notice, as claims for damages can only be asserted within the effective period for complaints.

3.2 Packaging

Please do not throw away the covering carton of your device as it might be useful for storage purposes, when moving or, in case of damages, when the device must be sent back to a repair center. The outer and inner packing material should be removed completely from the device before installation.



NOTE!

If you liked to dispose the packing, consider the regulations applicable in your country. Supply re-usable packing materials to the recycling.

Please inspect the device upon completeness. In case any part is missing please contact our customer service center immediately.

3.3 Storage


Keep the package closed until installation and under consideration of the outside indicated positioning- and storage markings.

Packages should be stored under consideration of the following:

- do not store outdoors,
- keep it dry and dust-free,
- do not expose it to aggressive media,
- do not expose it to direct sunlight,
- avoid mechanical shocks and vibration,
- in case of longer storage (> 3 months) make sure you check the state of the packaging and the parts regularly, if required refresh or renew.

4. Technical data

4.1 Overview of parts



- 1 Infrared lamp (2)
- 2 Ventilated aluminium reflectors (2)
- 3 Upper lamp holder
- 4 **ON/OFF** switch
- 5 Fixing bolt lamp holder
- 6 Height adjustment screw
- 7 Lower frame with pipe
- 8 1 container 1/1 GN

4.2 Technical specification

Name	Infrared food warmer 2WL550 1/1 GN
Code-no.:	114266
Material:	Aluminium
Realization:	<ul style="list-style-type: none">▪ 2 infrared lamps, output power heat lamp: 0.275 kW▪ Ventilated aluminium reflectors (2)▪ ON/OFF switch▪ Height-adjustable: 550 x 700 mm
Temperature range:	Max. 70°C
Power supply:	0.55 kW / 220-240 V 50 Hz
Clear height:	335 x 480 mm
Dimensions:	W 510 x D 345 x H 700 mm
Weight:	2.3 kg
Includes:	1 GN container 1/1 GN, 65 mm depth, stainless steel

We reserve the right to make technical changes!

5. Installation and operation

5.1 Instalation

Montage and positioning


- Unpack the device and dispose of all packing material.



WARNING

Never remove the rating plate or any warning signs from the device.

- The device must be assembled according to the instructions below (see drawing):



- Place the lower frame with pipe (1) on the flat surface:
- Place the included extension pipe (2) in the pipe (3) of lower frame.
- Screw in included infrared heating lamps.
- Fix the upper lamp holder with the infrared heating lamps (4) to the extension pipe (2) with use of lamp holder fixing bolt (5).
- Set required height of the upper lamp holder and fix it with use of height adjustment bolt (6) to the lower frame with pipe.
- Place the included GN 1/1 container (7) on the lower frame.
- Place the device on top of an even, stable, dry, and water-resistant surface which is not heat sensitive.
- **Never** place the device in humid or wet environment.
- **Never** place the device on the flammable surfaces.

- Pay attention to appropriate distance (min. 30 cm) from walls and other flammable or easily discoloured objects.
- The operational area around the device should be always clean and dry.
- Position the device in such way that the plug is easily accessible for quick disconnecting when required.

Connecting



DANGER! Electric shock hazard!

The device can cause injuries due to improper installation! Before installation and connecting the local power grid specification should be compared with that of the device (see type label). Connect the device only in case of compliance!

Connect the device only to properly installed single socket with protective terminal.

- The power supply circuit with the socket must be protected by the fuse at least 16A. Only connect the device directly to the wall socket, do not use any extension cords or power strips.

5.2 Operation

- Before the device operation clean it according to the instructions in section 6 “**Cleaning**”.
- Plug the device into a single grounded socket.
- Place selected hot food in appropriate GN 1/1 container under the infrared heating lamps on the lower frame to keep them heated from above.
- The device is equipped with 2 infrared heating lamps. Turn the infrared heating lamps on with use of switch.
- Pay attention to the distance between the infrared heating lamp and food. It should be approx. 30 cm.



WARNING

Only appropriate distance allows for reaching the perfect temperature for serving hot food without limiting their quality due to overcooking.



HOT SURFACE! Risk of burns!

The external surface of ventilated aluminium reflectors is very hot during their operation. Do not touch them with bare hands to avoid burns.

- When the device is not used turn it off with use of **ON/OFF** switch and remove the plug.

6. Cleaning



WARNING!

Before cleaning disconnect the device from the power supply (pull the plug!).

**The device is not suited for direct washing via water jets.
Protect the device from the water penetration.**

- Clean the device regularly.
- Clean the lower frame, upper lamp holder, and ventilated aluminium reflectors with use of moistened soft clothe and gentle cleaning agent.
- The GN container should be regularly washed in the running water with use of soft cloth and gentle cleaning agent. Washed GN containers should be rinsed with cleaned water and thoroughly dried.
- Use only soft cloth or sponge, never use any abrasive cleaning agents which may scratch the device.
- After cleaning dry and polish the surface with dry cloth.

Storage of the device

- If the device is not used for any lengthy period, clean it according to the aforementioned description and store it in dry, clean place protected against cold, sun and children. Do not place any heavy objects on the device.

7. Waste disposal

Discarding old devices

At the end of its service life the discarded device has to be disposed in accordance with the national regulations. It is advisable to contact a company which is specialized in waste disposal, or just contact the local disposal service in your community.



WARNING!

To exclude any abuse and the dangers involved make the waste device unfit for use before disposal. For that purpose disconnect device from mains supply and remove mains connection cable from the device.



CAUTION!



For the disposal of the device please consider and act according to the national and local rules and regulations.

Bartscher GmbH
Franz-Kleine-Str. 28
33154 Salzkotten
Germany

phone: +49 (0) 5258 971-0
fax: +49 (0) 5258 971-120